

## Kávový filtr CMF004 pro výměnu Brita Intenza



Filtr do kávovaru CMF004 byl navržen, aby zákazníkům nabídl vysoce kvalitní náhradu pro použití s kávovary a dalšími zařízeními využívajícími filtrační systém Brita Intenza. Instalace je totožná s instalací originálního filtru je u tohoto filtru nelze nastavit tvrdost vody ve spodní části filtru. Průtok filtru byl nastaven dle průměrných hodnot a tvrdosti vody.

### Příprava filtru pro použití

1. Před manipulací s filtrem si důkladně umyjte ruce. Vyjměte filtr z ochranného balení (polybagu), tento obal je recyklovatelný a lze jej zlikvidovat s většinou domácích plastů.
2. Pomocí čisté misky naplněné čerstvou studenou vodou, ponořte filtr a zatřeste s ním, aby se z filtru uvolnil veškerý zachycený vzduch.

### Nasadíte filtr

1. Vyjměte nádobku na vodu z kávovaru a vylijte veškerou zbývající vodu.
2. Pokud je v nádobě starý filtr, vyjměte filtr z nádobky. Nádobku doporučujeme umýt mýdlovou vodou, nádobku pořádně propláchněte studenou vodou, než vložíte nový filtr.
3. Vložte filtr do nádoby na místo. Ujistěte se, že je filtr pevně usazený a že se nemůže volně pohybovat, protože špatně nasazený filtr nepříznivě ovlivní její výkon kávovaru. Řiďte se pokyny s návodem od výrobce.

### Propláchněte a připravte filtr

1. Naplňte nádobku na vodu čistou, studenou vodou.
2. Nasadíte zpět nádobku na vodu do kávovaru.
3. \*Propláchněte filtr, buď spuštěním postupu výměny/propláchnutí filtru na vašem kávovaru NEBO pro kávovary bez tohoto programu spusťte dávkování „pouze horké vody“ (bez použití kávy), v případě potřeby nahlédněte do návodu a pokynů výrobce

\*v případě potřeby nahlédněte do pokynů výrobce.

### **Údržba**

Pravidelně vizuálně kontrolujte nádobku na vodu, abyste se ujistili, že kazeta zůstane usazená a filtrace funguje efektivně. Vyměňte filtr každých 250 šálků nebo každých 8 týdnů, podle toho, co nastane dříve.

Pokud stroj nebyl používán po dobu delší než dva týdny (například odjezd na dovolenou), doporučujeme před opětovným použitím vyměnit filtr.

### **Varování**

Před odstraňováním vodního kamene se vždy ujistěte, že je vyjmutý filtr z nádobky na vodu.

Řiďte se pokyny výrobce pro výměnu filtru.

## Coffee Filter to Replace Brita Intenza

### IMPORTANT

The CMF004 has been designed to offer customers a high quality replacement cartridge to be used with coffee machines and other appliances using the Brita Intenza filtration system.

Installation is identical to that of the original cartridge, however, there is no 'aroma adjustment' as the blending and flow has been calculated based on average usage and consumption during the filter design.

### Prepare the Cartridge

Thoroughly wash hands prior to handling the filter.

Remove the cartridge from the poly bag, this packaging is recyclable and can be disposed of with most household plastics.

Using a clean bowl filled with fresh cold water, submerge the cartridge and shake it to release any trapped air within the filter.

### Fit the Cartridge

With the water tank still fitted to the machine, remove the lid and firmly seat the cartridge into lock into place. Ensure cartridge is tightly fitted and there is no free-movement, as a poorly fitted cartridge will adversely affect its performance.

### Flush and Prepare

Remove the water tank from the coffee machine.

Fill the water tank with clean, cold water.

Refit the water tank to the coffee machine.

Rinse the filter, either by running the cartridge change/flush procedure on your coffee machine.

OR for machines without this facility by vending.

the first full tank of water through 'as hot water only' (without using coffee).

\* refer to manufacturers instructions where necessary.

### Maintenance

- Visually inspect the water tank periodically to ensure the cartridge remains seated and filtration is working effectively.

Replace cartridge every 250 cups or every 8 weeks, whichever comes first.

Where the machine has not been used for a period of more than two weeks (such as going on holiday) we would recommend replacing the filter prior to recommencing usage.

### Warning

Always ensure cartridges are removed before descaling appliance.